
Master
Client
sch_send
modulator
spread
chest_send
synch_send
rrc
Slot 0
Slot 1
Slot 2
STFA
rrc_rcv
chest_rcv
demodulator
sink
rndstr
modulator
chest_send
rrc
Slot 0
Slot 1
Slot 2
synch_rcv
rrc_rcv
sch_rcv
despread
demodulator
sink